





- AGGRESSIVE
- STRONG
- DOUBLE-SIDED
- QUICK INSTALL

Double-sided tape for moldings, trims, reducers, T-moldings, and more. Ideal for all types of flooring installations.

ALSO GREAT FOR BASE BOARDS AND SHOE MOLDINGS!

- 1. Substrates must be clean and flat.
- Apply tape to desired location for trim, molding, etc., or place tape on trim. Molding and trims made of fiberboard must be primed for a secure bond with the tape. Trim excess tape if necessary.
- 3. Using a utility knife, slide blade between release liner and tape to separate. Peel off liner completely from tape.
- 4. Place trim, moldings, etc. without applying any forceful pressure until ready for final permanent placement.

 Any forceful pressure will make the boards unmovable, because of the tape's strong initial bond.



MOLDINGTAPE 1/2 inch x 40 feet