


ER-180T Replacement Parts



Ref. No.	CRS Item No.	Description
01	101440	Cover, Printer ER-180/180T
02	101441	Cutter, Manual Paper ER-180
03	101442	Window, Rear ER-180/180T
04	101443	Window, Front ER-180/180T
05	101444	Cover, Display ER-180/180T
06	101308	Spool Winding ER-5200,15,40
07	101445	Cover, Battery ER-180/180T
08	434011	Roller Paper End LTPF347e
09	101456	Case, Upper ER-180T
10	101447	Switch, Mode ER-180/180T
11	101448	Motor, Takeup ER-180/180T
12	101449	Holder, Motor ER-180/180T
16*	101455	Platen Roller Assy ER-180T V.1
13	501758	Display Front ER-180T

Ref. No.	CRS Item No.	Description
14	101450	Harness, Power ER-180/180T
15*	101457	Housing, Clam ER-180T Ver.1
18*	101458	Holder Printer, ER-180T Ver.1
17	101452	Harness, Display FFC ER-180
19*	501756	Main Board Assy ER-180T Ver. 1
20	101454	Housing, Keyboard ER-180/180T
21	101309	Guide Winding ER-5200,15,40
23*	501754	Printer Assy ER-180T Ver. 1
15*	101482	Housing, Clam ER-180T Ver.2
16*	101481	Platen Roller Assy ER-180T V.2
18*	101483	Holder Printer ER-180T Ver.2
19*	501771	Main Board Assy ER-180T Ver.2
22*	101480	Power Adapter ER-180/180T Ver2
23*	501772	Printer Assy ER-180T Ver.2