


ER-180T Replacement Parts



| Ref. No. | CRS Item No. | Description |
|----------|--------------|--------------------------------|
| 01 | 101440 | Cover, Printer ER-180/180T |
| 02 | 101441 | Cutter, Manual Paper ER-180 |
| 03 | 101442 | Window, Rear ER-180/180T |
| 04 | 101443 | Window, Front ER-180/180T |
| 05 | 101444 | Cover, Display ER-180/180T |
| 06 | 101308 | Spool Winding ER-5200,15,40 |
| 07 | 101445 | Cover, Battery ER-180/180T |
| 08 | 434011 | Roller Paper End LTPF347e |
| 09 | 101456 | Case, Upper ER-180T |
| 10 | 101447 | Switch, Mode ER-180/180T |
| 11 | 101448 | Motor, Takeup ER-180/180T |
| 12 | 101449 | Holder, Motor ER-180/180T |
| 16* | 101455 | Platen Roller Assy ER-180T V.1 |
| 13 | 501758 | Display Front ER-180T |

| Ref. No. | CRS Item No. | Description |
|----------|--------------|--------------------------------|
| 14 | 101450 | Harness, Power ER-180/180T |
| 15* | 101457 | Housing, Clam ER-180T Ver.1 |
| 18* | 101458 | Holder Printer, ER-180T Ver.1 |
| 17 | 101452 | Harness, Display FFC ER-180 |
| 19* | 501756 | Main Board Assy ER-180T Ver. 1 |
| 20 | 101454 | Housing, Keyboard ER-180/180T |
| 21 | 101309 | Guide Winding ER-5200,15,40 |
| 23* | 501754 | Printer Assy ER-180T Ver. 1 |
| 15* | 101482 | Housing, Clam ER-180T Ver.2 |
| 16* | 101481 | Platen Roller Assy ER-180T V.2 |
| 18* | 101483 | Holder Printer ER-180T Ver.2 |
| 19* | 501771 | Main Board Assy ER-180T Ver.2 |
| 22* | 101480 | Power Adapter ER-180/180T Ver2 |
| 23* | 501772 | Printer Assy ER-180T Ver.2 |