


BTP-R180II Replacement Parts



Ref. No.	CRS Item No.	Description
01	132194	Cover, Top Black BTP-R180
02	132528	Cover, Cutter Black BTP-R180
03	132196	Cover, Middle Black BTP-R180
04	132197	Cover, Bottom Black BTP-R180
05	132138	Rubber Foot BTP-R580
06	417056	Gear, Platen Roller BTP-R580
07	417072	Sensor, Horz Paper Near End BTP-M300
08	132493	Auto Cutter Assy BTP-R880
09	132442	Gear, Printer 27-18 Bk-T080

Ref. No.	CRS Item No.	Description
10	132536	Gear, Transmission BTP-R180
11	132533	Print Head BTP-R180
12	501444	Cable, TPH BTP-2002/R180
14	132535	Motor, Step BTP-R180
15	132467	Power Switch BTP-L42
16	417071	Microswitch, End Cover BTP-M300
17	132479	Sensor, Paper Module BTP-R880NP
18	132538	Board, Button Feed BTP-R180
19	132534	Roller, Platen BTP-R180