

PORTABLE APPLIANCE TESTING (PAT) REPORT/CERTIFICATE

Original Certificate

Certificate
reference

: 00136764

DETAILS OF CLIENT

Client/ Address: MF Events UK, 102 Wentworth Way, Sanderstead, Surrey, CR2 9EW

TEST EQUIPMENT DETAILS

Test Equipment used	BATTPAT	Serial Number	ABPAT1428051
Tested by	P.W.Morton	Date	30/6/2023
		Retest Date	30/6/2024

Serial Number	Make and Model	Location	Voltage (V)	Rating (A)	Fuse rating (A)	Insulation resistance	Earth continuity	Plug, flex and body	OK to use ?
00001	FBT Promaxx 114a	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00002	FBT Promaxx 114a	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00003	Shure BLX Wireless Mic Kit	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00004	Pyrit Box Sub 112a	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00005	Pyrit Box Sub 112a	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00006	FBT J8a	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00007	FBT J8a	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00008	RCF Evox JMIX8 (W)	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00009	RCF Evox JMIX8 (W)	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00010	Equinox Helix XP (B)	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00011	Equinox Helix XP (B)	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00012	Equinox Helix XP (W)	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00013	Equinox Helix XP (W)	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00014	ADJ InnoSpot LED	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00015	ADJ InnoSpot LED	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00016	ADJ InnoSpot LED	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00017	ADJ InnoSpot LED	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00018	Cube LED	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00019	Cube LED	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00020	Pioneer DDJ-1000SRT	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00021	Marq Haze 800 Hazer	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00022	S & H Starcloth Unit	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00023	QTX DMX 10 Controller	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00024	ADJ DMX Controller	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00025	ADJ TriPar Profile Plus	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00026	ADJ TriPar Profile Plus	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00027	ADJ TriPar Profile Plus	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00028	ADJ TriPar Profile Plus	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00029	ADJ TriPar Profile Plus	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00030	ADJ TriPar Profile Plus	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00031	ADJ TriPar Profile Plus	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00032	ADJ TriPar Profile Plus	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00033	ADJ TriPar Profile Plus	Portable	240	5	5	>20MΩ	PASS	PASS	OK

Serial Number	Make and Model	Location	Voltage (V)	Rating (A)	Fuse rating (A)	Insulation resistance	Earth continuity	Plug, flex and body	OK to use ?
00034	ADJ TriPar Profile Plus	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00035	ADJ TriPar Profile Plus	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00036	ADJ TriPar Profile Plus	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00037	Pyrit Box Sub 112a	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00038	50m Ext Reel	Portable	240	10	10	>20MΩ	PASS	PASS	OK
00039	Equinox SpectraPix Batten	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00040	Equinox SpectraPix Batten	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00041	Varytec Spot 90W	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00042	Varytec Spot 90W	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00043	Powercon to IEC 1.5m	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00044	Powercon to IEC 1.5m	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00045	Powercon to IEC 1.5m (W)	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00046	Powercon to IEC 1.5m (W)	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00047	FBT J8a (W)	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00048	FBT J8a (W)	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00049	IMG WSA-24T	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00050	IMG WSA-24R	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00051	IMG WSA-24R	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00052	Q Audio HH Mic Receiver	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00053	Q Audio Lapel Mic Receiver	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00054	Trantec S4.4 Receiver	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00055	Trantec S4.04 lapel Receiver	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00056	SoundLab 2ch mixer	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00057	Acer Projector	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00058	Soundcraft EPM 6	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00059	Behringer Xenyx 1204	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00060	Lanta Laser	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00061	Lanta Laser	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00062	Unbranded DMX 10 Controller	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00063	Equinox Booth Starcloth Unit	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00064	Custom ADJ Gig Bar	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00065	Behringer 502 Mixer	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00066	Logitech Desktop Speakers	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00067	Equinox SpectraPix Batten	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00068	Equinox SpectraPix Batten	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00069	Equinox SpectraPix Batten	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00070	Equinox SpectraPix Batten	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00071	2m Y-Split IEC-3 Pin	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00072	2m Y-Split IEC-3 Pin	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00073	IEC14 – 3 Pin Socket	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00074	IEC14 – 3 Pin Socket	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00075	5m Ext Reel	Portable	240	10	10	>20MΩ	PASS	PASS	OK
00076	5m Ext Reel	Portable	240	10	10	>20MΩ	PASS	PASS	OK
00077	5m Ext Reel	Portable	240	10	10	>20MΩ	PASS	PASS	OK
00078	0.5m 4-Gang Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00079	0.5m 4-Gang Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00080	1m 4-Gang Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK

□ **PORTABLE APPLIANCE TESTING (PAT) REPORT/CERTIFICATE**

Serial Number	Make and Model	Location	Voltage (V)	Rating (A)	Fuse rating (A)	Insulation resistance	Earth continuity	Plug, flex and body	OK to use ?
00081	1m 4-Gang Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00082	1.5m 4-Gang Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00083	1.5m 4-Gang Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00084	1.5m Y-split IEC-3pin	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00085	1.5m Y-split IEC-3pin	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00086	IEC14 – 3 Pin Socket	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00087	5m Ext Reel	Portable	240	10	10	>20MΩ	PASS	PASS	OK
00088	5m Ext Reel	Portable	240	10	10	>20MΩ	PASS	PASS	OK
00089	5m Ext Reel	Portable	240	10	10	>20MΩ	PASS	PASS	OK
00090	5m Ext Reel	Portable	240	10	10	>20MΩ	PASS	PASS	OK
00091	5m Ext Reel	Portable	240	10	10	>20MΩ	PASS	PASS	OK
00092	5m Ext Reel	Portable	240	10	10	>20MΩ	PASS	PASS	OK
00093	5m Ext Reel	Portable	240	10	10	>20MΩ	PASS	PASS	OK
00094	5m Ext Reel	Portable	240	10	10	>20MΩ	PASS	PASS	OK
00095	5m Ext Reel	Portable	240	10	10	>20MΩ	PASS	PASS	OK
00096	5m Ext Reel	Portable	240	10	10	>20MΩ	PASS	PASS	OK
00097	T-Bar Y-split IEC-IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00098	T-Bar Y-split IEC-IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00099	2m Y-split IEC-3 Pin	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00100	1.4m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00101	IEC14 – 3 Pin Socket	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00102	2m 4-Gang Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00103	2m 4-Gang Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00104	1.5m IEC C7	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00105	1m IEC-IEC Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00106	1m IEC-IEC Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00107	0.5m IEC-IEC Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00108	2m IEC-IEC Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00109	3m IEC-IEC Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00110	1m IEC-IEC Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00111	1m IEC-IEC Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00112	0.5m IEC-IEC Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00113	0.5m IEC-IEC Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00114	4m Ext Reel	Portable	240	10	10	>20MΩ	PASS	PASS	OK
00115	4m Ext Reel	Portable	240	10	10	>20MΩ	PASS	PASS	OK
00116	4m Ext Reel	Portable	240	10	10	>20MΩ	PASS	PASS	OK
00117	4m Ext Reel	Portable	240	10	10	>20MΩ	PASS	PASS	OK
00118	4m Ext Reel	Portable	240	10	10	>20MΩ	PASS	PASS	OK
00119	0.5m 4-Gang Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00120	0.5m 4-Gang Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00121	0.5m 4-Gang Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00122	0.5m 4-Gang Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00123	0.5m 4-Gang Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00124	0.5m 4-Gang Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00125	0.5m IEC-IEC Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00126	0.5m IEC-IEC Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00127	10m Ext Reel	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00128	10m Ext Reel	Portable	240	13	13	>20MΩ	PASS	PASS	OK

□ **PORTABLE APPLIANCE TESTING (PAT) REPORT/CERTIFICATE**

Serial Number	Make and Model	Location	Voltage (V)	Rating (A)	Fuse rating (A)	Insulation resistance	Earth continuity	Plug, flex and body	OK to use ?
00129	30m Ext Reel	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00130	5m Y-Split IEC-3 Pin	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00131	5m Y-Split IEC-3 Pin	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00132	2m IEC – IEC Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00133	2m IEC – IEC Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00134	2m IEC – IEC Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00135	2m IEC – IEC Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00136	5m IEC – IEC Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00137	5m IEC – IEC Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00138	4m Ext Reel	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00139	5m 2-Gang Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00140	5m 2-Gang Ext	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00141	2.5m Y-split IEC-3 Pin	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00142	1.5m Y-split IEC-3 Pin	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00143	1.5m Y-split IEC-3 Pin	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00144	2m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00145	2m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00146	2m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00147	2m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00148	2m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00149	2m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00150	2m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00151	2m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00152	1.9m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00153	1.9m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00154	1.9m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00155	1.9m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00156	1.75m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00157	1.75m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00158	1.75m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00159	1.75m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00160	1.75m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00161	1.75m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00162	1.75m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00163	1.75m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00164	1.4m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00165	1.4m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00166	1.4m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00167	1.4m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00168	1.4m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00169	1.4m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00170	1.4m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00171	1.4m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00172	1.4m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00173	1.4m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00174	1.4m IEC	Portable	240	10	10	>20MΩ	PASS	PASS	OK
00175	1.4m IEC	Portable	240	10	10	>20MΩ	PASS	PASS	OK
00176	1.4m IEC	Portable	240	10	10	>20MΩ	PASS	PASS	OK

□ **PORTABLE APPLIANCE TESTING (PAT) REPORT/CERTIFICATE**

Serial Number	Make and Model	Location	Voltage (V)	Rating (A)	Fuse rating (A)	Insulation resistance	Earth continuity	Plug, flex and body	OK to use ?
00177	1.4m IEC	Portable	240	10	10	>20MΩ	PASS	PASS	OK
00178	1.4m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00179	1.4m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00180	1.4m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00181	1.4m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00182	1.4m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00183	1.4m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00184	1.4m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00185	1.4m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00186	1.4m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00187	1.4m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00188	1.4m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00189	1.4m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00190	1.4m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00191	1.4m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00192	1.2m IEC	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00193	1.2m IEC	Portable	240	5	5	>20MΩ	PASS	PASS	OK
00194	1m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00195	1m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00196	1m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00197	1m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00198	5m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00199	5m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00200	3.5m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00201	3m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00202	3m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00203	3m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00204	1.5m IEC	Portable	240	10	10	>20MΩ	PASS	PASS	OK
00205	1.5m IEC	Portable	240	10	10	>20MΩ	PASS	PASS	OK
00206	3m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00207	3m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00208	5m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00209	5m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00210	1m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00211	3m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00212	3m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00213	5m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00214	5m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00215	3m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00216	3m IEC	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00217	RCF 6X Mixer	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00218	Powercon 1.5m	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00219	Powercon 1.5m	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00220	Powercon 1.5m	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00221	Powercon 1.5m	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00222	Powercon 1.5m	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00223	Powercon 1.5m	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00224	Powercon 1.5m	Portable	240	13	13	>20MΩ	PASS	PASS	OK

□ **PORTABLE APPLIANCE TESTING (PAT) REPORT/CERTIFICATE**

Serial Number	Make and Model	Location	Voltage (V)	Rating (A)	Fuse rating (A)	Insulation resistance	Earth continuity	Plug, flex and body	OK to use ?
00225	Powercon 1.5m	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00226	Powercon 1.5m	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00227	Powercon 1.5m	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00228	Powercon 1.5m	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00229	Powercon 1.5m	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00230	Powercon 1.5m	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00231	Powercon 1.5m	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00232	Powercon 1.5m	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00233	Powercon 1.5m	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00234	The box pro DSP 110	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00235	The box pro DSP 110	Portable	240	13	13	>20MΩ	PASS	PASS	OK
00236	1.5m IEC	Portable	240	10	10	>20MΩ	PASS	PASS	OK
00237	1.5m IEC	Portable	240	10	10	>20MΩ	PASS	PASS	OK
00238	1.5m IEC	Portable	240	10	10	>20MΩ	PASS	PASS	OK

□

PORTABLE APPLIANCE TESTING (PAT) REPORT/CERTIFICATE

Repair Code Description

- 1 Replace 240v 13A plug – plastic
- 2 Replace 240v 13A plug – rubber
- 3 Change plug fuse 3A
- 4 Change plug fuse 5A
- 5 Change plug fuse 10A
- 6 Change plug fuse 13A
- 7 Replace 240v trailing socket
- 8 Replace 240v 16A plug
- 9 Replace 240v 16A connector
- 10 Replace 110v 16A plug
- 11 Replace 110v 16A connector
- 12 Replace 110v 16A panel mount socket
- 13 Trim, refit cable to appliance
- 14 Trim, refit cable to plug, or socket
- 15 Trim, refit cable to 240/110v 16A plug/connector/socket
- 16 Trim refit cable to 3-phase plug/connector/socket
- 17 Replace 15A/5A/2A plug
- 18 Trim, refit cable to fuse connection unit
- 19 Fit 10A flexible lead connector
- 20 Replace 1.5 Arctic Yellow/Blue cable 0-2m
- 21 Replace 1.5 Arctic Yellow/Blue cable 3-5m
- 22 Replace 1.5 Arctic Yellow/Blue cable 6-10m
- 23 Replace 1.5 Arctic Yellow/Blue cable 11 -1 5m
- 24 Replace 2.5 Arctic Yellow cable 0-2m
- 25 Replace 2.5 Arctic Yellow cable 3-5m
- 26 Replace 2.5 Arctic Yellow cable 6-10m
- 27 Replace 2.5 Arctic Yellow cable 11-15m
- 28 Replace 1.5 3 Core cable 0-2m
- 29 Replace 1.5 3 Core cable 3-5m
- 30 Replace 1.5 3 Core cable 6-10m
- 31 Replace 1.5 3 Core cable 11-15m
- 32 Replace 1.0 3 Core cable 0-2m
- 33 Replace 1.0 3 Core cable 3-5m
- 34 Replace 1.0 3 Core cable 6-10m
- 35 Replace 1.0 3 Core cable 11-15m
- 36 Replace 0.75 2 Core cable 0-2m
- 37 Replace 0.75 2 Core cable 3-5m
- 38 Replace 0.75 2 Core cable 6-10m
- 39 Replace 0.75 2 Core cable 11-15m
- 40 Supply 4 way extension lead complete
- 41 Supply and fit 4 way trailing socket
- 42 Supply and fit 2 way trailing socket
- 43 Supply kettle lead/complete with plug
- 44 Replace IEC plug/socket
- 45 Replace IEC computer lead
- 46 Replace cotton covered flex 2-3m
- 47 Fit 13A flex connector
- 48 Supply class 2 reversible mains lead
- 49 Fit 16/20/25mm cord grip bush
- 50 Fit strain relief bush

□