

What is an ice dam?

Ice dams are usually caused by heavy snowfall and poor attic ventilation. Snow melts under the surface and accumulates as ice in the gutters. Water can't drain, leading to a backup that can damage ceilings and walls.

