


ER-5115II Series Replacement Parts



Ref. No.	CRS Item No.	Description
01	102259	Cover, Printer 5115-II N/S
02	102016	Cover-Mode Switch ER-5100
03	300537	Samsung Control Lock
04	542000	Printer Assy M-U420
05	500996	Keyboard Assy ER-5115-II N/S
06	160257	Drawer Model 57 ECR Ivory 24V
07	102019	Display Window ER-5100/5140
08	102018	Window Turret 5100/5140

Ref. No.	CRS Item No.	Description
09	501342	Display Rear 380,5115-II,5200
10	102017	Turret Body ER-5100
11	102260	Case, Upper 7000/5200/5115 N/S
12	501481	Display Front ER-5115-II
13	501506	Logic Board ER-5115-II
14	202999	Transformer 655/350-II/650-II/51
15	501349	Pba Sub-Power SW ER-5200,15,40
16	101310	Case Lower ER-5200,15,40